

INCLUDES:

Oil Bubbler & Stem
Trap Stand
Tubing Cleaners
Oil Bubbler Stand [500ml only]

Oil Trap & Stem
Tubing
Check Valve

Destruct
Connectors
Extra Destruct Material

Ozonated Oil Making System - 500ml or 1000ml



What you need for a standard setup: Destruct, Check Valve, Tubing, two Luer fits, Oil Trap and Oil Bubbler. Extra Destruct Material and Tube Cleaners can be put aside until you need them.

1. Fill the oil bubbler with the desired amount of oil. Put the stem back in the bottle and place the bottle in its stand (1000ml does not need or have a stand).
2. Place the oil trap stem into the trap and place the trap in its stand.
3. If you do not already have a check valve installed with your ozone unit, connect the check valve between your ozone generator and the oil bubbler as shown.

4. With the check valve in place, connect the silicone tubing coming from the ozone out on your ozone generator to the Ozone In straw of the oil bubbler (*the one that goes all the way into the oil*). Connect a piece of silicone tubing to the other stem of the bubbler and attach the end of that tubing to the Ozone In straw on the oil trap (*the one that goes further into the jar*).

5. Connect a piece of silicone tubing to the Ozone Out straw of the oil trap and attach the other end to the Destruct.