


Using a 200ml Ozone Syringe




1. Attach the included check valve tubing (diagram below) to the Ozone Out on the ozone generator using the male adapter. **Do not attach this syringe directly to the generator.** Attach the syringe to the other side (female) of the check valve tubing. Once it's full, disconnect the syringe and hold it with the tip facing up.



VIDEO


2. Attach a catheter to the syringe. When you're ready to begin your insufflation, slowly press the plunger in to push ozone out of the syringe.



Using 60ml, Glass and Plastic Syringes with Ozone



VIDEO



1. Attach the syringe directly to the Ozone Out on the ozone generator. Once it's full, disconnect the syringe and hold it with the tip facing up.

2. Attach a catheter for rectal or vaginal insufflations or a syringe cover for sinus insufflations (catheter shown below).

3. When you're ready to use ozone, press the plunger in to push ozone out of the syringe.

