


## Using the Oil Breathing Bubbler and Cannula - All sizes



1. Attach your check valve and tubing kit to the Ozone Out of your ozone generator, then attach the other end to the long straw on the oil bubbler (the one that goes all the way into the jar).
2. Attach your nasal cannula to the other straw of the oil bubbler.
3. If your bubbler came with a stand (200ml or 500ml), place the bubbler in the stand and fill it with your choice of oil until it covers the diffuser at the bottom.